


Dogness Rover App Feeder User Manual

F16



BEFORE USING THIS PRODUCT, PLEASE READ THIS MANUAL

Thank you for purchasing DOGNESS smart products. For your safety and concern, please read this product manual carefully prior to use. Failure to follow and operate this product in accordance within the manual and issues that result in any personal injury property or other losses. DOGNESS has no liability except as expressly provided by law.

ABOUT THE PRODUCT MANUAL

The authorization, trademark, and font size of the manual belong to DOGNESS and other related parties. If the content of the manual is inconsistent with the actual product (including APP), the actual product (APP) shall prevail, DOGNESS reserves the right (including electronic version) to interpret and modify the manual within the scope permitted by law. If you have any objection to any content or terms of the manual, please submit a written objection to DOGNESS: within 7 days after purchasing the product. Otherwise you agree, understand and accept the entire contents within this user manual.


AUTHORIZATION STATEMENT

The company respects and protects the personal rights of all users who use the service. In order to provide you with accurate and personalized services this product will use and share your personal device operation rights in accordance with the authorized directions. This application will treat this information with a high degree of diligence and prudence. Except as otherwise provided in this authorization statement, this product will not disclose or provide this information to third parties without your prior permission.


Additional users authorized by you to access the product will have the usage rights of your device, including but not limited to: function, control, video recording, photography, microphones, listening, etc. The decision to authorize means that you are fully aware and understood the above terms. The company does not assume any form of responsibility for the loss of personal privacy, relationship disputes, property, credit, etc. as a result. Please use caution with the authorization function. The company has the final right to interpret the license terms, and the authority to terminate the service agreement with the authorized user(s) immediately.

PRODUCT CONTENTS









SPECIFICATIONS

Size: | 13.8"x W7.99" x H12.68"

Rechargeable Battery: 5000mAh

Network: 2 4GHz & 5GHz Wi-Fi

smartphone to replenish the supply.

Simple to disassemble and clean,

· AI COMPATIBILITY: Alexa.

FEATURES

Product Name: Dogness Rover App Feeder

Material: ABS, Stainless Steel ABS, Melamine

*The device needs to be used with a 5V/1A power adaptor.

Smartphone Compatibility: Android 5 or above, iPhone 7 or above

Includes: Feeder, USB Power Cord , Food Bowl, User Manual & Warranty

food outlet closure prevent insects from entering while reducing moisture.

DURABLE: Detachable thickened food bowl, wear-resistant and easy to clean.

• CAPACITY: Holds up to 4 liters of dry kibble, feeds up to 12 meals per day 39 portions per meal.

· CLOG - FREE DISPENSER: Anti-food jamming design ensures the food is delivered on time, every time.

• INSECT & MOISTURE-RESISTANT: Built-in top cover silicone seal keeps the food fresh and dry. The

• DUAL-POWER MODE: Powered with a USB power cord and rechargeable lithium battery, supports

• LOW FOOD NOTIFICATION: When the food level is low, it will automatically send a notice to your

· REMOVABLE TRANSPARENT BUCKET: With the transparent bucket it's easy to see the food level.

PAW PROOF: Push-and-pull lid and food outlet closure keep it inaccessible to prving paws.




USB Powercord X1


User Manual X1

Warranty Card X1

NOTE: In an effort to provide the best user experience for you and your pet, our products are continually updated and improved. Therefore this user manual may have slight differences from the actual product.

PRODUCT OVERVIEW







Built-In Rechargeable Battery

POWER SUPPLY

SLEEP MODE:

When using battery power, after a short idle period, the feeder will enter low-power sleep mode to conserve energy. Functions of the

feeder will be limited to the scheduled feeding plan and notifications. Full functions will be

restored including the camera when the app

Note: The picture is for reference only, please refer to the real product.

Power Button: When connected to power press the power button to ensure the feeder is turned on.



Scan the QR code to download the "Dogness"App

Android/iOS download

Power on the feeder by plugging the USB cord and adaptor into a power outlet. Press the power button to ensure the feeder is turned on Make sure both your smartphone and the feeder using the same Wi-Fi networks. [2.4 Ghz and 5 Ghz Wi-Fi networks are available]

close proximity to the WiFi router.

INSTALL THE DOGNESS APP FEEDER & SMARTPHONE PAIRING



The feeder can be connected to the App using three different methods: 1. Scanning of the QR code on the feeder, 2. Bluetooth pairing or connecting the device via hot spot, 3. Manual Set-up [most commonly used]. The feeder is operational once it is connected to your Wi-Fi network.

Description of the indicator light functions	
Function	Description
Reset Button	Pressing twice will manually feed 1 serving. Press and hold for 6 seconds until it makes a "DingDong" sound to reset the feeder.
Food Detection Sensor Light	When the food level is at or less than 25% full, the yellow light will begin to flash.
Wi-Fi Indicator Light & Food Blockage Detection Light	Green indicator Light: 1. Slow Flash; configuration mode, feeder is ready to connect to your Wi-feedwork. 2. Fast Flash; pairing mode, feeder is attempting to connect to the Wi-Finetwork. 3. Solid Light; connected, normal operation. Red Indicator Light:
	Slow Flash: Food is Blocked. OFF: In Sleep Mode & Battery Powered.
Power Light	Battery Charging: Solid Red Light Charging Complete: Solid Green Light Low Battery: Flashing Red Light Normal Operation: Light is Off

PRECAUTIONS

- 1. Fill the food bucket before using the feeder for the first time.
- 2. When plugging and unplugging the adapter, do not pull on the power cord directly.
- 3. Don't insert foreign objects into the feeder, modify or attempt to repair this product without prior authorization from a Dogness representative.
- 4. Please use original USB power cable.
- 5. When the food level indicator light is on the feeder contains about 50 portions only[5g estimate for each portion). Please add food ASAP.
- 6. This product is only suitable for indoor use, avoid direct sunlight exposure.
- 7. This device contains electronic parts and is not waterproof. It is not recommended to be used in moist or wet environments.
- 8. This product is not suitable for any other purposes except feeding pets
- 9. This is not a toy, those who lack relevant experience and knowledge (including children) must use it under the supervision and guidance of a responsible adult.
- 10. Clean and maintain this product.

- Q. Why is the indicator light on when i first use it?
- A. Fill the bucket with dry food above the sensor window and press the reset button and the light will disappear.
- Q: Why cant i connect the feeder to the internet?
- A: Check the network (Wi-Fi) configuration, then press and hold the button on the feeder for 6 seconds to re-set it (beep), and release. Wait for the green light to start to flash slowly, follow the set-up process on the app, enter your Wi-Fi account user name and password, and reconnect.
- Q. Is there another way to connect to the feeder?
- A. Try using the device "hot spot" connection method. On the page where the App failed to connect, click the orange font "Reconnect to device hot spot connection mode" which is under "Reconnect". Before using the hot spot connection, press the RESET button for 2 seconds until the indicator light flashes blue, then enter the device selection page, select the device to be connected, and follow the prompts.
- Q. Why wont the food dispense?
- A. The food bucket may be empty or the Wi-Fi network is disconnected or delayed or it could be obstructed.
- Q. What can I do if my App account suddenly fails to login?
- A. First, make sure that the network is normal and if you share the feeder with a friend check to see if they're logged into the account. Otherwise, it is recommended to reinstall the App again, Android users can clear the cache by going to settings in their smartphone and try again.
- Q. I want to change my account number and information within the App. how do i do that? A. The App does not support direct replacement of the account. It's suggested to set-up and register a new
- account using a different email address or phone number than previously used. Make sure to uninstall and reinstall the App.
- If you have any other questions, please visit our website at https://www.dogness.com.

Entrusting Party: Dogness Group LLC

Address of Entrusting Party: 4116 W Spring Creek Pkwy, Plano, TX 75024

Manufacturer: Jiasheng Enterprise Co., Ltd.

Address of Manufacturer: No. 3 W Yuehua Rd, Tongsha New Industry Park, Dongguan,

Guangdong, China 523127

Website: www.dogness.com

To maintain a reliable network connection, please place the feeder within

DOWNLOAD THE APP OR SCAN THE OR CODE TO INSTALL