

Racing Chase

-Cat Toy

Instruction



Operation / Function Description

. Install cat-teasing accessories

The feather part is attached to the end of the toy or the rope with bell is tied to the end of the toy.

. ON/OFF

Press and hold the ON/OFF button for 2 seconds to turn on or turn off

. Smart Standby / Power Saving Design

When the toy is turned on for 4 minutes, the wheel with light will turn red and shine once in 2 seconds indicating that enter the standby state. to continue using the toy, you need to touch it to activate it. If not activated, the toy will automatically turn off after 6 hours.

. Battery Reminding Function

When the wheel with light suddenly turns red and flash quickly in the process of using, indicating that the power is low.

. State Of Charge

Using the standard TYPE-C to charge, a red breathing light on the wheel indicating charging, after it being fully charged in about 30 minutes turns to color.

Specification

Item Name:	Racing Chase Cat Toy
Model No:	MDE2800
Target species:	cat
Main materials:	ABS,TPR
Dimensions:	64mm x 57mm x 26mm (without tail)
Weight:	40g
Battery:	240mah
Input:	5V == 0.5A

NOTES

- . Do not use on the plush carpet, it may get involved in the plush and cause the wheel get stuck.
- . When the toy runs slowly, check whether the wheel is involved in the hair, can remove the wheel to clean the hair.
- . Toys are not suitable for dogs and should not be washed. If necessary, they can be wiped clean with a cloth.
- . Feathers are wearing parts of toys. can buy the replacement or DIY other funny accessories after damage.
- . Natural feathers are sterilized at high temperature, please rest assured use.
- . No toy is indestructible, for pets only and keep out of reach of children, always better to be supervised while playing with this toy.

Made In China