

Dogness App Feeder Mini User Manual



### BEFORE USING THIS PRODUCT, PLEASE READ THIS MANUAL

Thank you for purchasing DOGNESS smart products. For your safety and concern, please read this product manual carefully prior to use. Failure to follow and operate this product in accordance within the manual and issues that result in any personal injury, property or other losses, DOGNESS has no liability except as expressly provided by law.

#### ABOUT THE PRODUCT MANUAL

The authorization, trademark, and font size of the manual belong to DOGNESS and other related parties. If the content of the manual is inconsistent with the actual product (including APP), the actual product (APP) shall prevail. DOGNESS reserves the right (including electronic version) to interpret and modify the manual within the scope permitted by law. If you have any objection to any content or terms of the manual, please submit a written objection to DOGNESS; within 7 days after purchasing the product. Otherwise you agree, understand and accept the entire contents within this user manual.

### AUTHORIZATION STATEMENT

The company respects and protects the personal rights of all users who use the service. In order to provide you with accurate and personalized services, this product will use and share your personal device operation rights in accordance with the authorized directions. This application will treat this information with a high degree of diligence and prudence. Except as otherwise provided in this authorization statement, this product will not disclose or provide this information to third parties without your prior permission.

Additional users authorized by you to access the product will have the usage rights of your device, including but not limited to; function, control, video recording, photography, microphones, listening, etc. The decision to authorize means that you are fully aware and understood the above terms. The company does not assume any form of responsibility for the loss of personal privacy, relationship disputes, property, credit, etc. as a result. Please use caution with the authorization function. The company has the final right to interpret the license terms, and the authority to terminate the service agreement with the authorized user(s) immediately.

## **SPECIFICATIONS**

Product Name: Dogness App Feeder Mini

Model: F05

Size: L 13.6" x W 7.4" x H 10.2"

Weight: 2.65 lbs. Capacity: 2 Liters

Material: ABS / Stainless Steel

Network: Wi-Fi 2.4GHz (not compatible with 5GHz. WiFi)

Application: Dogness App

Power: Input 100-240V 50/60Hz 0.4A; Output 5.0V, 1000mA, Back-up power with

3 "D" batteries (not included)

Includes: Feeder, Stainless Steel Bowl, USB Powercord & Adapter.

# FEATURES

- Anti-food jamming design ensures the food is delivered on time, every time.
- Built-in top cover silicone seal keeps the food dry and fresh. The food outlet closure keeps insects and moisture away.
- Automatic Pet Feeder controlled through the free Dogness App.
- Schedule up to 6 meals per day.
- Set 1-15 portions per meal.
- Low food notifications sent directly to your smartphone.
- Removable Stainless Steel bowl.
- Speaker and Microphone to Record an announcement prior to each meal.
- 10'ft. USB Power cord with Adapter and Battery back up requires 3 "D" sized batteries (not included).
- Compatible with Android and iOS Smartphone.
- · Download the free Dogness APP.

#### PRODUCT OVERVIEW BATTERY BACK-UP





Android 5.0 version or above IOS 7.0 version or above





DOWNLOAD THE APP OR SCAN THE OR CODE TO INSTALL

SET-UP



INSTALL THE DOGNESS APP







Make sure both your smartphone and the feeder are using the same 2.4Ghz Wi-Fi network. (not compatible with 5Ghz Wi-Fi).

MANUAL FEEDING: Short press the button to dispense food. RESET THE FEEDER: Press and hold the button for 6 seconds to restore to the factory setting. WI-FI STATUS LIGHT: Fast Flashing = Connecting. Sold Green = Connected

NOTE: Battery power provides the minimal amount to maintain the established feeding plan. It does not provide sufficient power to maintain a network connection. Battery power should be used only during power failures or outages

## FEEDER & SMARTPHONE PAIRING



Entrusting Party: Dogness Group LLC Address of Entrusting Party: 4116 W Spring Creek Pkwy, Plano, TX 75024

Manufacturer: Jiasheng Enterprise Co., Ltd.

Address of Manufacturer: No. 3 W Yuehua Rd, Tongsha New Industry Park, Dongguan,

Guangdong, China 523127

Website: www.dogness.com

Customer Service Hotline (U.S.): 1-833-DOGNESS (364-6377)

Follow the instructions within the APP to connect the Feeder to your smartphone. You can begin using once they are paired.

	Light Color Defintions & Functions
Function	Description
Manual Feed / Reset Button	1. Press and hold the buton for one second to manually feed 1 portion. 2. In configuration mode, the green light flashes slowly (0.5 second dark, 0.5 second bright). 3. In the configuration mode or connected state, long press the RESET button for more than 6 seconds hear "OID" for reset operation, green light will flash quickly before it flashes slowly, and then restar the network connection. After the network is successfully connected, the indicator light will be solid.
Food Level Light (yellow)	No light = Food Level is higher than 25%.     Rashing Light - Food Level below 25%, the light will turn off when food Is added.     The light function can be turned on/off in the APP.
Wi-Fi Indicator Light	1. Green indicator light: 1) Slow flash-Configurable status; 2) Flashing-Connecting to network; 3) SolidNetwork connection successful. 2. Blue indicator light: 1) Slow flash-AP configurable status; 2) Flashing-Connecting to network; 3) Solid-Connection successful.
Wi-Fi StatuS Light	Yellow indicator light: Turns on when device is powered by batteries only and power is low     Red indicator light: Turns on if the device is defective, or if the product is damaged     Green indicator light: Default light when the food is being released (Users can set accordingly on the App).
Voice Recording Function	Open the Dogness App, go to settings, Recording settings.Add Recording click the recording button on your smartphone to talk to the device, release the recording button. click the Trial and listen to the recording.

#### PRECAUTIONS

- 1. Do not unplug by pulling on the power cord. To unplug, grasp the plug, not the power cord.
- 2. Do not insert any foreign objects into the feeder, or attempt to open or repair the feeder.
- 3. Use the original power adapter and cable only.
- 4. When the food level indicator light is on, the feeder contains about 13 portions remaining, please
- 5. The battery back-up uses three Alkaline "D" size, which last up to 10 days under normal use.
- 6. Feeder is suitable for indoor use only.
- 7. Device is to be used for the purpose of feeding a pet and not for an other uses.
- 9. DO NOT use wet, canned or moist food.
- 10. Feeder should be placed on a level surface.
- 11. To reduce the risk of injury, close supervision is necessary when an appliance is used by or near
- 12. Do not allow pets to chew on or swallow any parts. If you are concerned about the power cord, use the power cord.
- 13. Keep the electrical cord away from water.
- Not Diswasher Safe.
- 15. Cleaning: unplug from electricity, clean with a mild soap cleaner, dry with a cotton cloth an air dry.

correct account password and reconnect.

connected, and follow the prompts.

Answer: Please try the following:

the bin is empty or not.

- 1. What's the reason why the feeder can't be connected to the Internet?
- Answer: Please try the following: 1) Check whether the machine is powered on, If not, make sure the machine is powered on, If yes, see

SET button for 6 seconds, when the green light flashes slowly, follow the prompts on the App, enter the

3) If the connection fails, you can use the device hotspot connection method. On the page where the App

failed to connect, click the orange font "Reconnect to device hotspot connection mode" which is under

4) If you still cannot connect to the network, please contact customer service: 1-833-Dogness (364-6377). 2. Why there is no food dispensed into the food bowl when the App sends a feeding command?

1) The rotating shaft is rotating but the food can not be detected. We suggest that you to check whether

2) It Maybe caused by network delay or disconnection. Repeated feeding is suggested to check if it is

Answer: First, make sure that the network connection is normal, and then check if someone else is

3) It is suggested to clean out the food oulet to avoid excessive accumulation.

"Reconnect", Before using the hotspot connection, press the RESET button for 2 seconds until the indicator light turns blue flashing state, then enter the device selection page, select the device to be

- 8. Use only Dry Pet food kibbles.

- a power cord conduit (a hard plastic protector) that can be purchased at any hardware store to protect

- logging into your account. Otherwise, it is recommended that you uninstall the App and reinstall the App, and then try to login again. If your phone uses android system, you can also try the following: Your phone-- setting-- application management-- DOGNESS- -clear data-- clear cache, and then login. 4. I want to change the account number of the App, which is being used. What should I do? Answer: Our App does not support direct transfer of the account. If you really need to change, please 2) Check whether the network configuration is a 2.4G channel network or a 5G channel network. If it is a register a new account with a new email address and unbind the feeder under the original account. And 5G channel network, you need to switch to the 2.4G channel network environment. Then long press the
  - Remark: When binding or rebinding a new account, long press the RESET button for 6 seconds. When the green light flashes slowly, reconnect upon hearing the sound of "Di Di".
  - 5. If you have any other questions, please visit the website below for more information:
  - http://www.dognessnetwork.com/help/index.html

then bind the feeder under the new account.

# LIMITATION OF LIABILITY

In no event, under any cause of action or theory of liability, shall Dogness, its affillates or distributors be liable for any indirect incidental, consequential or punitive damages, of any nature whatsoever, arising out of the use of or inability to use any Dogness product(s), including without limitation, property damage, loss of value of product(s) that are used in or with Dogness products(s). You agree and understand. Dogness has no liability for any damage, loss of data or destruction to consumer electronic devices or other personal property including, without limitation, cellular phones, tablets, laptops or other devices. Regardless of the legal theory on which a claim is based, shall limit the recovery of any kind against Dogness not to be greater in amount than the purchased price of the product, if any.

NOTE: In an effort to provide the best experience for you and your pet, we continually make updates and improvements to our products periodically. This user manual may have slight differences from the actual product.